



# An Excel Application for Analysis and Design of RC Low-Rise Structural Elements using British Standards and European Codes

Kisasati Wekesa Jacob<sup>1</sup>, Owino Emily Achieng<sup>1</sup>, Mburu Rose Nunga<sup>1</sup>, Omar Salim Makumba<sup>1</sup>, Ann Muganda<sup>1</sup>, Clement K. Kiptum<sup>1</sup>  
<sup>1</sup>(Department of Civil and Structural Engineering, University of Eldoret, Kenya)

**Abstract:** There is an increasing demand for tools that can simplify the design process and improve the accuracy and efficiency of the design calculations in structural engineering. This paper presents an Excel application for the design and analysis of reinforced concrete low-rise structures using British standards and European codes. The application aims to assist structural engineers in the design process as it provides a set of pre-programmed calculations for the analysis of slabs, beams, columns, footings and stairs. The application incorporates the relevant design equations and guidelines from both standards and allows the user to input the required parameters and generate concise design outputs such as load capacity, stress analysis results and design recommendations. In developing the application, a combination of VBA programming and yield line method was used. The application has been tested using different design scenarios and the output compared to manual calculations. The application offers significant time savings, increased accuracy, and improved efficiency over manual methods.

**Keywords:** Beam, British standards, Columns, European codes, Excel application, Footing, Slabs, Stairs, structural engineering, low-rise structures, VBA programming, yield line method, design, analysis.

## 1. Introduction

The design and analysis of structures, such as buildings, bridges, and tunnels, require complex calculations to ensure their safety and durability [1]. Structural analysis can be done quickly using commercial software like SAP 2000 and ETABS [2], other software includes RISA 3D, Prokon, SAFE, Tekla structural designer among others [3]. Manual calculations are time-consuming, prone to error, and require a great deal of experience and expertise. As a result, there is a need for a user-friendly tool that can assist engineers and designers in their design calculations. Several excel applications have been previously developed for the design of structural elements [4]. This study presents an Excel application that has been developed to perform analysis and design of reinforced concrete low-rise structural elements using British Standards [5] and European Codes [6]. The Application comprehensively performs reinforced concrete structural analysis and design as per Eurocode and British Standards by calculating reactions, displacements, bending moments, shear forces and axial forces for static loads on a plane frame structure using the specified tables and Moment distribution method of analysis. Only distributed gravity loads are considered. The structural elements designed by the application are slabs, beams, columns, footings and stairs.

We built the application in Microsoft Excel using Visual Basic for Applications (VBA) programming language, which allowed us to automate the calculations and generate the output data automatically [7]. VBA was used by [8] to design reinforced cement concrete beams using spreadsheets, however, spreadsheets can be used to design several elements [9].

There are several advantages to using this Excel application for the design of structural elements using British Standards (BS) and Eurocodes (ECs). Firstly, time-saving: This application significantly reduces the time required for structural design as it automates the calculations and provide immediate results. Secondly, accuracy: there is reduced risk of calculation errors that are common in manual calculations. This is because they use built-in formulas and functions that have been designed to minimize calculation errors. Thirdly, consistency: all calculations done by the application are consistent and follow the same design procedures because they are programmed to use the same design codes and procedures for all calculations. Also, flexibility: this application can be customized to suit the specific needs of the user. This means that users can design structures based on their own preferences and design criteria. Another advantage is portability: the application can be easily shared among team members and clients. Lastly, documentation: the Excel application can generate detailed reports of the design calculations. This can help users to keep track of the design process and provide documentation for future reference. The results of the spreadsheets can be compared to manual calculation for validation purposes as done by [10].

The main objectives include:

- To develop an excel application



- To develop design sheets for slabs, beams, columns, footings and stairs.
- To use structural engineering concepts in the excel sheets.
- To incorporate the use of British Standards and European codes in the design sheets

## 2. Methodology

### 2.1 Overview of the Developed Application

The developed Excel application is an excel workbook that consists of 8 tabs. Relevant design equations and guidelines in the application have been obtained from British Standards European code. The green cells in each of the tabs requires the user to enter or select data from the dropdown. The user can also print the entire tab or select the cells to print using the “SELECT” and “PRINT PDF” options in each tab.

#### Tab 1: Home.

This contains the RCC workbook information. It also allows the user to select the desired code between the British Standards and European codes.

#### Tab 2: Solid Slab

Presents the design of slabs according to the code previously selected. The sheet designs solid slabs both one way and two-way slabs which can be continuous, simply supported slab and the cantilever slabs. The excel performs deflection and cracking checks.

#### Tab 3: Beam design

Entails the design of beams upto 15 spans. The Excel carries out analysis and design of simply supported and continuous beams which can either be T-beam, L-beam and R- beam using Moment Distribution Method for analysis and yield line method to calculate the slab areas. The user can input moments and shear forces obtained from third party software. The application does design for the critical span and the same reinforcement details provided for all the spans and also the critical support in which the same reinforcements are also provided for all the supports.

#### Tab 4: Beam shear design

Presents the design of shear reinforcement. Maximum shear forces are used in the design and the reinforcements obtained provided for all spans. The user then checks for deflection and cracking

#### Tab5: Columns size

The program recognizes three types of columns; perimeter column, internal column and corner column. Tributary area method is used to determine the load carried by the column. The user should note if the structure has a roof or roof slab. The user can also perform calculation of tank load on the roof slab if their structure has any. The user is allowed to select the type of column section to adopt from either a rectangular, circular section

#### Tab6: Column design

This tab deals with column design. The user can perform analysis and design of axially loaded columns with no significant moments acting on them. The program sums up the loads from slabs, beams, walls, parapet if any and even the column self-weights to get the cumulative axial loads of columns in each story levels. The reinforcement areas of steel can be directly obtained and the user can directly print the output and start detailing. The program can be used in column design up to eight story levels.

#### Tab7: Pad footing

The tab deals with the design of pad footing. Presents the design of rectangular or square footing. The user is required to check if the punching shear, transverses hear and face shear are satisfactory.

#### Tab8: combined bases

Besides the calculations, the sheet presents a visual representation of a combined footing.

#### Tab9: staircase

The tab presents the design of staircases. The strip method (1m width strip) is used for the design. This Excel also incorporates the check for deflection upon entering the required fields. This tab also shows staircase plan and side elevation for visual interrogation.

## 2.2 Operating the Application

Upon installing and opening the application, a message box is displayed. The user then clicks “OK” to enable the program.




Fig 1: Snapshot the Message box

### Tab 1: Home.

This tab displays the RCC workbook information button and the code to select button. Upon clicking the RCC workbook information button, more information is displayed. The user then selects the code to use from the dropdown.




Fig 2: Snapshot of the Home Tab

### 2.2.1 Design of Slabs

#### Tab 2: Solid slab.

This is the first element to design. The user performs the following steps:

1. Enter the story height, average diameter of coarse aggregate,  $h_{agg}$
2. Select whether to calculate the slab thickness or input as per your engineering experience
3. Enter the span length, select cover and then enter the assumed diameter.
4. Select the class of concrete, and the strengths of the reinforcing bars and the density of concrete.



5. Input the loads on partitions, services and finishes and also the live loads
6. Select the type of panel to design for. Enter the dimensions of the slab. The excel determines the type of slab based on load distribution i.e., two way or one way
7. Enter the length of the shorter span when designing for a one way or cantilever solid slab.
8. Select the required areas to determine the size and spacing of the reinforcement.
9. The excel does the overall checks for deflection and cracking then advises if the reinforcements provided are satisfactory or not.

Eurocode		Materials		Design Checks: (DEFLECTION CHECK)	
Storey Height	3000	f <sub>ck</sub>	25	Design moment:	2.86
h <sub>eff</sub> (mm)	20	f <sub>yk</sub>	500	A <sub>s</sub> required	58
		f <sub>yk</sub>	250	A <sub>s</sub> provided	393
Initial Proportioning		Final proportioning		Eurocode DEFLECTION CHECK	
H-Calculat	3400	1.35	1.5	Deflection Span	3400 mm
Span	3400	Concrete density	24	Effective depth	120 mm
mfactor	1.3	Permanent actions - Gk		Area Check:	Span < 7m m.f = 1.00
Basic-Ratio	26	Self-weight	3.60	Actual L <sub>ud</sub>	28.33
Cover	25	Partitions	0.00	% of A <sub>s, reqd</sub>	p = A <sub>s, reqd</sub> /bd 0.0005
Assumed, Φ	10	Services/Finishes	3.00	Ref. rebar ratio	p <sub>re</sub> = (f <sub>ck</sub> ) <sup>1/2</sup> 0.0050
dmin	101	Total Permanent actions - G	6.60	% of A <sub>s, reqd</sub>	p' = A <sub>s, reqd</sub> /bd 0.0000
Hmin	131	Imposed actions - Qk		TB 7.4N, K	1.3
H	150	EN 1991-1-1, TB 6.1 & 6.2	0.60	Basic ratio	26
d	120	Total ultimate actions, n	9.81	Allowable s <sub>10</sub>	eq (7.16.a), TB 7.4N 709.35
Deflection is Checked and is OK					
BS 8110-1, CL 3.5.3.4		Interior Panels		Two way	
β <sub>s</sub> , BS 8110-1, TB 3.14	Moments:	K for b=1000	Z <sub>max</sub>	Z <sub>max</sub>	A <sub>s</sub> reqd
β <sub>sx</sub> -	0.0328	3.72	0.0103	118.90	114.00
β <sub>sx</sub> +	0.0252	2.86	0.0079	119.15	114.00
β <sub>sy</sub> -	0.0320	3.63	0.0101	118.92	114.00
β <sub>sy</sub> +	0.0240	2.72	0.0076	119.19	114.00
One way Solid Slab, Lx:	1500	2.76	0.0077	119.18	114.00
Cantilever Solid Slab, Lx:	1400	9.62	0.0267	117.10	114.00
SIMPLY SUPPORTED SLAB ( BS 8110-1, TB 3.13 )					
Simply Supported Slab: α	0.0655	7.43	0.0206	117.77	114.00
Simply Supported Slab: α	0.0617	7.00	0.0194	117.91	114.00
BAR SIZE AND SPACING		SELECT YOUR AREAS:		Cranking Control design	
Φ <sub>(MIN)</sub>	150	175	200	225	250
10	524	449	393	349	314
12	754	646	565	503	452
16	1340	1149	1005	894	804
20	2094	1795	1571	1396	1257
25	3272	2805	2454	2182	1963
32	5362	4596	4021	3574	3217
As min	CL 9.2.1.1				160
As prov	Ensure deflection ok				393
As max	CL 9.2.1.1(3)				6000
min spacing	Eurocode 2, CL 8.2 (2)				25
Spacing Provided	Ensure deflection ok				200
Max spacing	CL 9.3.1.1(3)				400
Overall Check:	Cracking control is checked & satisfactory				

Fig 3 : Snapshot of the solid slab Tab

### 2.2.2 Design of Beams

When designing for a beam, the user is required to:

#### Tab 3: Beam Design

1. Type in the beam number intended for design, the height of the beam, width of the beam web, width of the wall, the unit weight of wall material used
2. Select
  - if the beam to design is a T-beam, L-beam or R-beam
  - select the number of spans in the beam
3. Enter the span widths of the beam. If L-beam, enter the widths of one side and if T- beam or R-beam enter the widths of both sides. The program generates the maximum sagging moments, maximum hogging moments and the maximum shear force in the entire beam.
4. Incorporate Moments and shear forces obtained from third party software if need be. Select whether to use the moments obtained by excel or the inputted moments.
5. Select design of sagging reinforcement to design for spans. Select design of hogging reinforcement to design for supports.
6. Enter the class of concrete to use
7. Provide reinforcement details using the area provided. Select the area required to determine the number of bars and the diameter that can be used.
8. Enter the details of the reinforcement bars as preferred in the first and second layer.



COMPLETE DESIGN AND CHECKS FOR BEAMS AS PER EUROCODE 2					CONFIRM & SELECT																																																																																																																	
<table border="1"> <tr> <td>BEAM 1</td> <td><math>h_{beam}</math></td> <td>450</td> <td><math>H_{slab}</math></td> <td>150</td> <td><math>Y_{wall}</math></td> </tr> <tr> <td></td> <td><math>b_{web}</math></td> <td>200</td> <td>Beam <math>h_{web}</math></td> <td>300</td> <td></td> </tr> <tr> <td></td> <td><math>b_{wall}</math></td> <td>200</td> <td><math>H_{wall}</math></td> <td>2550</td> <td>18</td> </tr> <tr> <td rowspan="4">Eurocode</td> <td>Gk-slab</td> <td>6.60</td> <td>n-slab</td> <td>9.81</td> <td>kN/m<sup>2</sup></td> </tr> <tr> <td>Masonry Load: (Gk)</td> <td>9.18</td> <td>Masonry Load: (n)</td> <td>12.393</td> <td>kN/m</td> </tr> <tr> <td>Beam load: (Gk)</td> <td>1.44</td> <td>Beam load: (n)</td> <td>1.944</td> <td>kN/m</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>					BEAM 1	$h_{beam}$	450	$H_{slab}$	150	$Y_{wall}$		$b_{web}$	200	Beam $h_{web}$	300			$b_{wall}$	200	$H_{wall}$	2550	18	Eurocode	Gk-slab	6.60	n-slab	9.81	kN/m <sup>2</sup>	Masonry Load: (Gk)	9.18	Masonry Load: (n)	12.393	kN/m	Beam load: (Gk)	1.44	Beam load: (n)	1.944	kN/m						<table border="1"> <tr> <td><math>M_{min}</math>MDM:</td> <td>68.64</td> <td><math>M_{SUPPORT}</math>:</td> <td>105.36</td> <td><math>V_{MAX}</math>:</td> <td>113.32</td> </tr> <tr> <td><math>M_{min}</math>User:</td> <td>44.00</td> <td><math>M_{SUPPORT}</math>:</td> <td>72.00</td> <td><math>V_{MAX}</math>:</td> <td>75.00</td> </tr> <tr> <td><math>M_{SPAN}</math>:</td> <td>46.00</td> <td><math>M_{SUPPORT}</math>:</td> <td>72.00</td> <td><math>V_{MAX}</math>:</td> <td>75.00</td> </tr> </table>	$M_{min}$ MDM:	68.64	$M_{SUPPORT}$ :	105.36	$V_{MAX}$ :	113.32	$M_{min}$ User:	44.00	$M_{SUPPORT}$ :	72.00	$V_{MAX}$ :	75.00	$M_{SPAN}$ :	46.00	$M_{SUPPORT}$ :	72.00	$V_{MAX}$ :	75.00																																																								
BEAM 1	$h_{beam}$	450	$H_{slab}$	150	$Y_{wall}$																																																																																																																	
	$b_{web}$	200	Beam $h_{web}$	300																																																																																																																		
	$b_{wall}$	200	$H_{wall}$	2550	18																																																																																																																	
Eurocode	Gk-slab	6.60	n-slab	9.81	kN/m <sup>2</sup>																																																																																																																	
	Masonry Load: (Gk)	9.18	Masonry Load: (n)	12.393	kN/m																																																																																																																	
	Beam load: (Gk)	1.44	Beam load: (n)	1.944	kN/m																																																																																																																	
$M_{min}$ MDM:	68.64	$M_{SUPPORT}$ :	105.36	$V_{MAX}$ :	113.32																																																																																																																	
$M_{min}$ User:	44.00	$M_{SUPPORT}$ :	72.00	$V_{MAX}$ :	75.00																																																																																																																	
$M_{SPAN}$ :	46.00	$M_{SUPPORT}$ :	72.00	$V_{MAX}$ :	75.00																																																																																																																	
<table border="1"> <tr> <td colspan="2">Selected Beam Section</td> <td>T SECTION</td> <td><math>\Phi_{link}</math></td> <td>8</td> <td>mm</td> </tr> <tr> <td colspan="2">Beam Longest Span (mm)</td> <td>5100</td> <td>Cover, C</td> <td>25</td> <td>mm</td> </tr> <tr> <td colspan="2">Beam flange Width, <math>b_f</math></td> <td>1755</td> <td>d</td> <td>409</td> <td>mm</td> </tr> <tr> <td colspan="2">Designing a Continuous Beam T SECTION</td> <td></td> <td>d'</td> <td>41</td> <td>mm</td> </tr> <tr> <td colspan="2">DESIGN OF SAGGING REINFORCEMENT: SPAN MOMENT =:</td> <td></td> <td></td> <td></td> <td>46</td> </tr> </table>					Selected Beam Section		T SECTION	$\Phi_{link}$	8	mm	Beam Longest Span (mm)		5100	Cover, C	25	mm	Beam flange Width, $b_f$		1755	d	409	mm	Designing a Continuous Beam T SECTION			d'	41	mm	DESIGN OF SAGGING REINFORCEMENT: SPAN MOMENT =:					46	<table border="1"> <tr> <th colspan="5">BEAM DESIGN TO EUROCODE 2</th> </tr> <tr> <td><math>f_{yk}</math></td> <td>500</td> <td>N/mm<sup>2</sup></td> <td><math>f_{yv}</math></td> <td>250</td> <td>N/mm<sup>2</sup></td> </tr> <tr> <td><math>f_{ck}</math></td> <td>25</td> <td>N/mm<sup>2</sup></td> <td><math>b_{eff}</math></td> <td>1755</td> <td>mm</td> </tr> <tr> <td>K</td> <td>0.006</td> <td><math>K_{rel}</math></td> <td>0.167</td> <td colspan="2">No Comp. rebars</td> </tr> <tr> <td>Z</td> <td>406.73</td> <td><math>Z_{bal}</math></td> <td>388.55</td> <td><math>Z_{TO USE}</math></td> <td>388.55</td> </tr> <tr> <td>X</td> <td>51.13</td> <td><math>X_{CHECK}</math></td> <td>251.54</td> <td colspan="2">Yielding checked &amp; OK</td> </tr> <tr> <td><math>A_s</math></td> <td>0</td> <td><math>A_{s REQ}</math></td> <td>273</td> <td colspan="2">mm<sup>2</sup></td> </tr> </table>	BEAM DESIGN TO EUROCODE 2					$f_{yk}$	500	N/mm <sup>2</sup>	$f_{yv}$	250	N/mm <sup>2</sup>	$f_{ck}$	25	N/mm <sup>2</sup>	$b_{eff}$	1755	mm	K	0.006	$K_{rel}$	0.167	No Comp. rebars		Z	406.73	$Z_{bal}$	388.55	$Z_{TO USE}$	388.55	X	51.13	$X_{CHECK}$	251.54	Yielding checked & OK		$A_s$	0	$A_{s REQ}$	273	mm <sup>2</sup>																																											
Selected Beam Section		T SECTION	$\Phi_{link}$	8	mm																																																																																																																	
Beam Longest Span (mm)		5100	Cover, C	25	mm																																																																																																																	
Beam flange Width, $b_f$		1755	d	409	mm																																																																																																																	
Designing a Continuous Beam T SECTION			d'	41	mm																																																																																																																	
DESIGN OF SAGGING REINFORCEMENT: SPAN MOMENT =:					46																																																																																																																	
BEAM DESIGN TO EUROCODE 2																																																																																																																						
$f_{yk}$	500	N/mm <sup>2</sup>	$f_{yv}$	250	N/mm <sup>2</sup>																																																																																																																	
$f_{ck}$	25	N/mm <sup>2</sup>	$b_{eff}$	1755	mm																																																																																																																	
K	0.006	$K_{rel}$	0.167	No Comp. rebars																																																																																																																		
Z	406.73	$Z_{bal}$	388.55	$Z_{TO USE}$	388.55																																																																																																																	
X	51.13	$X_{CHECK}$	251.54	Yielding checked & OK																																																																																																																		
$A_s$	0	$A_{s REQ}$	273	mm <sup>2</sup>																																																																																																																		
<table border="1"> <tr> <th colspan="5">T-BEAM (Designed as T)</th> </tr> <tr> <td></td> <td>SPAN LENGTH</td> <td>ONE SIDE LENGTH</td> <td>OTHER SIDE LENGTH</td> <td>YieldLine-AREAS</td> <td>1.35GK: Loads</td> <td>N: Loads</td> <td>MDM</td> </tr> <tr> <td>6</td> <td>3.50</td> <td>3.40</td> <td>2.80</td> <td>6.00</td> <td>29.61</td> <td>31.15</td> <td></td> </tr> <tr> <td>1</td> <td>3.00</td> <td>3.40</td> <td>2.80</td> <td>4.49</td> <td>27.67</td> <td>29.02</td> <td></td> </tr> <tr> <td>2</td> <td>3.50</td> <td>3.40</td> <td>1.00</td> <td>4.56</td> <td>25.95</td> <td>27.12</td> <td></td> </tr> <tr> <td>3</td> <td>4.00</td> <td>5.00</td> <td>5.00</td> <td>8.00</td> <td>32.16</td> <td>33.96</td> <td></td> </tr> <tr> <td>4</td> <td>5.10</td> <td>5.00</td> <td>5.00</td> <td>13.00</td> <td>37.05</td> <td>39.34</td> <td></td> </tr> <tr> <td>5</td> <td>5.00</td> <td>5.00</td> <td>3.00</td> <td>11.50</td> <td>34.83</td> <td>36.90</td> <td></td> </tr> </table>					T-BEAM (Designed as T)						SPAN LENGTH	ONE SIDE LENGTH	OTHER SIDE LENGTH	YieldLine-AREAS	1.35GK: Loads	N: Loads	MDM	6	3.50	3.40	2.80	6.00	29.61	31.15		1	3.00	3.40	2.80	4.49	27.67	29.02		2	3.50	3.40	1.00	4.56	25.95	27.12		3	4.00	5.00	5.00	8.00	32.16	33.96		4	5.10	5.00	5.00	13.00	37.05	39.34		5	5.00	5.00	3.00	11.50	34.83	36.90		<table border="1"> <tr> <td>Select bars for <math>A_{s req}</math></td> <td>First Layer:</td> <td>2</td> <td>16</td> <td rowspan="2"><math>A_s PROVIDED:</math></td> <td rowspan="2">402</td> </tr> <tr> <td></td> <td>Second Layer:</td> <td>0</td> <td>12</td> </tr> <tr> <td colspan="2">Number of Bars</td> <td colspan="3">Select the required Area</td> <td>273</td> </tr> <tr> <td>Bar Size</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> </tr> <tr> <td>12</td> <td>226</td> <td>339</td> <td>452</td> <td>565</td> <td>679</td> </tr> <tr> <td>16</td> <td>402</td> <td>603</td> <td>804</td> <td>1005</td> <td>1206</td> </tr> <tr> <td>20</td> <td>628</td> <td>942</td> <td>1257</td> <td>1571</td> <td>1885</td> </tr> <tr> <td>25</td> <td>982</td> <td>1473</td> <td>1963</td> <td>2454</td> <td>2945</td> </tr> <tr> <td>32</td> <td>1608</td> <td>2413</td> <td>3217</td> <td>4021</td> <td>4825</td> </tr> </table>	Select bars for $A_{s req}$	First Layer:	2	16	$A_s PROVIDED:$	402		Second Layer:	0	12	Number of Bars		Select the required Area			273	Bar Size	2	3	4	5	6	12	226	339	452	565	679	16	402	603	804	1005	1206	20	628	942	1257	1571	1885	25	982	1473	1963	2454	2945	32	1608	2413	3217	4021	4825
T-BEAM (Designed as T)																																																																																																																						
	SPAN LENGTH	ONE SIDE LENGTH	OTHER SIDE LENGTH	YieldLine-AREAS	1.35GK: Loads	N: Loads	MDM																																																																																																															
6	3.50	3.40	2.80	6.00	29.61	31.15																																																																																																																
1	3.00	3.40	2.80	4.49	27.67	29.02																																																																																																																
2	3.50	3.40	1.00	4.56	25.95	27.12																																																																																																																
3	4.00	5.00	5.00	8.00	32.16	33.96																																																																																																																
4	5.10	5.00	5.00	13.00	37.05	39.34																																																																																																																
5	5.00	5.00	3.00	11.50	34.83	36.90																																																																																																																
Select bars for $A_{s req}$	First Layer:	2	16	$A_s PROVIDED:$	402																																																																																																																	
	Second Layer:	0	12																																																																																																																			
Number of Bars		Select the required Area			273																																																																																																																	
Bar Size	2	3	4	5	6																																																																																																																	
12	226	339	452	565	679																																																																																																																	
16	402	603	804	1005	1206																																																																																																																	
20	628	942	1257	1571	1885																																																																																																																	
25	982	1473	1963	2454	2945																																																																																																																	
32	1608	2413	3217	4021	4825																																																																																																																	

Figure 4: Snapshot of the Beam Design Tab

**Tab 4: Beam shear design**

- 9 Enter the assumed column height and width.
- 10 Select the number of legs, the diameter and the spacing to use in providing the details of the links.
- 11 Check if the deflection and cracking control check are satisfactory.

SHEAR REINFORCEMENTS DESIGN AND CHECKS TO EUROCODE 2:																																																					
SHEAR REINFORCEMENTS DESIGN			DEFLECTION CHECKS AND VERIFICATION				CRACKING CHECKS AND VERIFICATION																																														
d	409	mm	Deflection Span: L	5100	mm	Total height, h	450	mm																																													
$f_{yk}$	500	N/mm <sup>2</sup>	Effective depth: d	409	mm	$b_{web}$	200	mm																																													
$f_{ck}$	25	N/mm <sup>2</sup>	$b_{web}$	200	mm	$b_{eff}$	1755	mm																																													
$A_{s req}$	273	mm <sup>2</sup>	ACTUAL CONDITIONS OF THE BEAM			Cover, C	25	mm																																													
First Layer:	2	16	Actual L/d	12.47		$\Phi_{LINK}$	8	mm																																													
Second Layer:	0	12	PERMISSIBLE CONDITIONS UNDER SERVICE			AREA CHECKS & VERIFICATIONS																																															
$A_{s prov}$	402	mm <sup>2</sup>	$f_{ck}$	25	N/mm <sup>2</sup>	Eurocode 2, & TB 3.1 (Row 5) ( $A_{s MIN}$ )																																															
Assumed Col:	200	200	$A_{s REQUIRED}$	273	mm <sup>2</sup>	$f_{ctm}$	2.56	mm <sup>2</sup>																																													
$N_{Ed}$	75.00	kN	$A_{s PROVIDED}$	402	mm <sup>2</sup>	$A_{s min}$	109	mm <sup>2</sup>																																													
$N_{MAX}$	26.95	kN/m	$\rho_s = (f_{yk})^{1/2}$	0.005		Eurocode 2, CL 9.2.1.1(3) ( $A_{s MAX}$ )																																															
$Y_{concrete}$	1.5		$\rho = A_{s req} / b_w d$	0.0033		$A_{s max} = 4.0\%$	3600	mm <sup>2</sup>																																													
$V_{Ed}$	61.28	kN	$\rho' = A_{s' req} / b_w d$	0		$A_{s req}$ :	273	mm <sup>2</sup>																																													
SHEAR GEOMETRY IN DEGREES			Factor for structural system, K	1.3		$A_{s PROVIDED}$	402	mm <sup>2</sup>																																													
$\alpha$	45		Checks:	Use equation (1)		AREA OF REBARS CHECK & VERIFICATION																																															
Cot	1		L/d	36.2206843		$A_{s MIN} < A_{s PROV} < A_{s MAX}$ <b>PASS</b>																																															
tan	1		$\sigma_s$	210.4575443	N/mm <sup>2</sup>	SPACING CHECKS & VERIFICATIONS																																															
DIMENSIONS CHECK			Allowable L/d	53.35		BS 8110-1, TB 3.28 (Maximum Spacing)																																															
V	0.54	N/mm <sup>2</sup>	<b>DEFLECTION CHECK IS SATISFACTORY</b>																																																		
$V_{REL MAX}$	Beam dimensions satisfactory																																																				
$V_{REL C}$	48.718	kN																																																			
$A_{s SW/S MIN}$	0.16	N/mm <sup>2</sup>																																																			
$A_{s SW/S}$	0.38	N/mm <sup>2</sup>																																																			
Provide 4 Legs of T			<table border="1"> <tr> <th>No. of legs:</th> <th>4</th> <th colspan="9">Link spacing</th> </tr> <tr> <td>8</td> <td><math>\Phi LINKS:</math></td> <td>100</td> <td>125</td> <td>150</td> <td>175</td> <td>200</td> <td>225</td> <td>250</td> <td>275</td> <td>300</td> </tr> <tr> <td>@</td> <td>8</td> <td>2.02</td> <td>1.60</td> <td>1.34</td> <td>1.14</td> <td>1.00</td> <td>0.90</td> <td>0.80</td> <td>0.74</td> <td>0.68</td> </tr> <tr> <td>200</td> <td>10</td> <td>3.14</td> <td>2.52</td> <td>2.10</td> <td>1.80</td> <td>1.58</td> <td>1.40</td> <td>1.26</td> <td>1.14</td> <td>1.04</td> </tr> </table>							No. of legs:	4	Link spacing									8	$\Phi LINKS:$	100	125	150	175	200	225	250	275	300	@	8	2.02	1.60	1.34	1.14	1.00	0.90	0.80	0.74	0.68	200	10	3.14	2.52	2.10	1.80	1.58	1.40	1.26	1.14	1.04
No. of legs:	4	Link spacing																																																			
8	$\Phi LINKS:$	100	125	150	175	200	225	250	275	300																																											
@	8	2.02	1.60	1.34	1.14	1.00	0.90	0.80	0.74	0.68																																											
200	10	3.14	2.52	2.10	1.80	1.58	1.40	1.26	1.14	1.04																																											
Cracking control checked and is satisfactory																																																					

Figure 5: Snapshot of Shear Design Tab

**2.2.3 Design of Columns**

**Tab 4: Column Size**

1. The user is required to enter the beam length (m) supporting the slab the column will carry.
2. The initial size of the column b and h are assumed in mm
3. Enter parapet wall height(mm) and length(m)
4. Enter slab area(m<sup>2</sup>)
5. In case of tanks supported on the roof slab, enter the tank volume, roof slab thickness and finishing loads (kN/m<sup>2</sup>) and live load (kN/m<sup>2</sup>).



Design of Perimeter Column_Roof				7	Wall Loads	N	Etabs - Loads	N <sub>Ed</sub>	Rectangular Section:		
Safety Factor	Gk	1.35	f <sub>concrete</sub>	24	Floor-6	0.00	62.37	0.00	62.37	N <sub>Ed</sub> =	1287.75
	Qk	1.50	f <sub>Wall</sub>	18	Floor-5	99.14	266.60	0.00	266.60	AC =	64387.58
Load types	Sections	Loads		Floor-4	99.14	470.83	0.00	470.83	cd, b =	200	SELECT:
Beam Loads	Beam, h (mm)	450	15.55	Floor-3	99.14	675.06	0.00	675.06	cd, h =	350	PRINT:
	Beam, b (mm)	200		Floor-2	99.14	879.29	0.00	879.29	CHECK	COLUMN SECTION	
Column Loads	Column, h (mm)	2550	3.30	Floor-1	99.14	1083.52	0.00	1083.52	Circular Section:		
	Column, b (mm)	200		Ground Floor	99.14	1287.75	0.00	1287.75	Diameter:	300	
Wall Loads	Wall, b (mm)	200	99.14								
	Wall, h (mm)	2550									
	Parapet, h (mm)										
Slab Loads	Parapet, L (m)		0.00								
	Slab, h (mm)	150									
Slab Loads	Slab, n (kN/m <sup>2</sup> )	9.81	86.23								
	Slab area (m <sup>2</sup> )	8.79									
Roof Load											
Dead load: Gk =	2	Live load: Qk =	1.5	n = 43.52 kN							

Figure 6: Snapshot of Column Size Tab

**Tab 5: Column Design**

1. Class of concrete to be used.
2. The cover of the column based on durability and exposure conditions of the column.
3. The type of column selected from the dropdown arrow.
4. End conditions of the column
5. The reduction factor from the dropdown arrow provided.
6. The area to be used in providing reinforcement in mm<sup>2</sup>.

Design of Perimeter Column_Roof				FLOORS	N <sub>Ed</sub>	M <sub>Ed</sub>	N <sub>Ed</sub> /bh <sub>0</sub> f <sub>ck</sub>	M <sub>Ed</sub> /bh <sup>2</sup> f <sub>ck</sub>	A <sub>t,req</sub> /bh <sub>0</sub>	A <sub>s,Req</sub>	A <sub>s, Provided</sub>	Links	Link Spacing	Spacing at lap		
Beam	200	h <sub>column</sub>	200	Floor-6	64.85	0.00	0.03	0.000	0	140	4	12	452	8	200	100
Beam	450	h <sub>column</sub>	350	Floor-5	269.06	0.00	0.13	0.000	0.05	210	4	12	304	8	200	100
f <sub>ck</sub>	30	f <sub>ck</sub>	500	Floor-4	473.31	0.00	0.23	0.000	0.35	1470	4	12	Re-PROVIDE	8	200	100
bh <sub>0</sub> f <sub>ck</sub>	2.10	bh <sup>2</sup> f <sub>ck</sub>	0.735	Floor-3	677.54	0.00	0.32	0.000	0	156	4	12	1963	8	200	100
Beam L, Long	3	Column height		Floor-2	881.77	0.00	0.42	0.000	0	203	8	12	6434	8	200	100
Beam L, Short	3	Column height		Floor-1	1086.00	0.00	0.52	0.000	0	280	4	12	452	8	200	100
Beam Size	200	450	3	Ground Floor	1289.23	0.00	0.61	0.000	0	297	4	12	452	8	200	100
K <sub>1</sub>		K <sub>2</sub>														
253125	189843.75															
Stiffnesses																
Beam:	1518750000	Stiffness factor, I <sub>B</sub>	0.167													
Column:	714583333.3	Stiffness factor, I <sub>C</sub>	0.125													
I <sub>C</sub>	0.470507545	Stiffness factor, I <sub>C</sub>	0.125													
Area of slab	Loads, q and 1.35q		28.71	124.12680												
FEM	86.12595		128.68													
A <sub>s, min</sub>	140	A <sub>s, max</sub>	2800													
Φ <sub>bar</sub>	16	Φ <sub>link</sub>	8													
Cover to Rebars	30	d	304													
α <sub>1</sub>	46	d <sub>eff</sub> /h	0.13													
0.20																

N <sub>Ed</sub> /bh <sub>0</sub> f <sub>ck</sub>	M <sub>Ed</sub> /bh <sup>2</sup> f <sub>ck</sub>	A <sub>t,req</sub> /bh <sub>0</sub>
0.03	0.000	0
0.13	0.000	0.05
0.23	0.000	0.35
0.32	0.000	0
0.42	0.000	0
0.52	0.000	0
0.61	0.000	0

Figure 7: Snapshot of Column Design Tab

**2.2.4 Design of Footing**

**Tab 6: Pad Footing**

In the design of pad footing, the user undertakes the following steps:

1. Select the ultimate service conversion factor from the options 1.37, 1.4, 1.45, 1.5
2. enter the allowable bearing pressure of the site location
3. select the desired shape of footing, either the square footing or the rectangular footing
4. enter the desired dimensions of the footing bearing in mind the calculated areas



5. enter the class of concrete, cover and the assumed diameter.
6. Enter the eccentricity values
7. Select the reinforcement bars and spacing
8. Check if the punching shear, transverse shear and face shear are satisfactory




Figure 8: Snapshot of Pad Footing Tab

**Tab 7: Combined Bases**

The user is required to:

9. Select the class of concrete and the cover
10. Enter the distance between the column centers
11. Enter the column loads from the two columns
12. select the ultimate service conversion factor, enter the bearing capacity of the area
13. enter the desired dimensions of the rectangular footing bearing in mind the dimensions calculated by the software
14. In the preliminary proportioning, enter the size of the first and second column, the assumed diameter of the bar.
15. Enter the diameter and spacings in the design of reinforcement




Figure 9: Snapshot of Combined Bases Tab



**Tab 8: staircase**

- The user is required to input the following data
  - The number of risers in one side of the stairs
  - Height of each riser
  - Length of each thread
  - Effective span
  - Concrete density to be used
  - Live load
  - Strength of steel reinforcement
  - Strength of shear reinforcements
  - Strength of concrete
- Depending on the area of steel reinforcements required and minimum reinforcement needed, the user chooses the diameter of bar to be used and the spacing of reinforcement to be provided.
- The distribution reinforcements are provided based on the minimum required area of reinforcement. The excel checks the deflection and confirms it satisfactory or not.




Figure 10: Snapshot of Staircase Tab

### 3. Conclusion

The Excel Application is a very useful tool in the design of reinforced concrete lowrise structural elements such as the slabs, beams, columns, footings and stairs using British standards and Eurocodes. This application has been tried using different scenarios and has not only proven to be user- friendly but also is more accurate, saves a lot of time and paper when compared to manual calculations. Also, the user has the liberty to input data obtained from other design tools and softwares during the design process to aid in their design.

### References

- [1]. D. Proske, " The Collapse Frequency of Structures,," *Buildings and structures.*, pp. 89-109., 2022.
- [2]. M. & W. J. Alhassan, ". Incorporating very Powerful Structural Analysis and Design Software Packages into Civil Engineering Courses.,," in *Annual Conference & Exposition*, 2010.
- [3]. Samson Olalekan ODEYEMI, "Evaluation of Selected Software Packages for Structural," *ABUAD Journal of Engineering Research and Development*, vol. 3, no. 2, pp. 133-141, 2020.
- [4]. S. & C. S. P. Tattimani, " Developing an individual Excel sheet for design and analysis of beam and slab. ,," *International Journal for Research in Applied Science and Engineering Technology*, 10(9), 703-730, 2022.
- [5]. C. E. Reynolds, Examples of the design of reinforced concrete buildings to BS8110 (4th ed.), . CRC Press., (2017).
- [6]. A. Alexandrou, Introduction to Eurocode 2: Design of concrete structures., CRC Press, (2017).
- [7]. R. Mansfield, Mastering VBA for Microsoft office, John Wiley & Sons., 2013.





- 
- [8]. S. T. & V. Shrivastav, "Development of Design Spreadsheet Tool for R.C.C. Beam Design using V.B.A.," *IJIRST –International Journal for Innovative Research in Science & Technology*, vol. 4 , no. 11, pp. 1-10, 2018.
- [9]. N. T. e. al., "Automated Excel Sheets for Various RC Elements," *International Journal for Research in Applied Science and Engineering Technology*, vol. 6, no. 11, pp. 596-602, 2018.
- [10]. A. B. A. Mrityika Hasan Rodela, "Comparative Study between Manual Analysis and Computer Software Analysis (ETABS) of a Residential Building in Dhaka City," in *CSBMACSARBDC*, Dhaka City, 2019.